

THE ECO FENCE SYSTEM
IS AN ASSEMBLY OF
TWO PANELS

Note:
See page 57 for bracket selection.


The center to center spacing is 2" and 3" post is 95 9/16" 2427mm

PANEL HEIGHT	NUMBER OF FOLDS PER PANEL	NUMBER OF BRACKET KITS PER POST	
		END POSTS	MID/LINE POSTS
1245 mm (4'H)	2	2	2
1549 mm (5'H)	2	3	3
1778 mm (6'H)	3	3	3
2464 mm (8'H)	4	4	4

FOR MORE INFORMATIONS ON THESE PANELS, PLEASE REFER TO SPECIFICATIONS.


OMEGA ECO BRACKET KITS






DOUBLE ANGLE BRACKET KIT 2", 3" □ 4" WITH OMEGA ECO FOR END POSTS



NOTES:
FOR COLORS OTHER THAN BLACK, ALL PARTS ARE
POLYESTER POWDER COATED EXCEPT NUTS □ BOLTS.

DOUBLE ANGLE BRACKET KIT 2", 3" □ 4" WITH OMEGA ECO FOR MID POSTS





THE ECO FENCE SYSTEM
IS AN ASSEMBLY OF
TWO PANELS

Note:
See page 57 for bracket selection.

The center to center spacing is 2" and 3" post is 95 9/16" 2427

PANEL HEIGHT	NUMBER OF FOLDS PER PANEL	NUMBER OF BRACKET KITS PER POST	
		END POSTS	MID/LINE POSTS
1245 mm (4'H)	2	2	2
1549 mm (5'H)	2	3	3
1778 mm (6'H)	3	3	3
2464 mm (8'H)	4	4	4

FOR MORE INFORMATIONS ON THESE PANELS, PLEASE REFER TO SPECIFICATIONS.


SQUARE POSTS
INSTALLATION WITH
ANGLE BRACKET
KIT 14 GA

1 - GRADING

THE GROUND SHALL BE GRADED TO AN EASY EVEN SLOPE ALL ALONG THE LENGTH OF THE AREA WHERE THE FENCE IS TO BE INSTALLED.

2 - INSTALLATION

- INSTALL THE FENCE ALONG THE SPECIFIED AREA. THE FENCE SHALL BE INSTALLED A DISTANCE OF A MINIMUM OF 1" (25 MM) AND MAXIMUM OF 2" (50 MM) ABOVE THE GROUND SURFACE.
- INSERT ALL THE POSTS VERTICALLY AT THEIR PROPER HEIGHT IN CONCRETE. ONCE THE CONCRETE IS SET, THE MESH SECTIONS ARE FASTENED TO THE POSTS WITH THE UNIVERSAL BRACKET KITS 2", 3" OR 4". THE BRACKET'S SLOT ALLOWS FOR ADJUSTMENTS OF ±1-1/2" (38MM).
- WHEN ANY POST OR WIRE MESH SECTION IS FIELD CUT OR TRIMMED FOR FIT, A ZINC RICH PRIMER MUST BE APPLIED TO THE EXPOSED ENDS. AFTER, AN OMEGA TOUCH-UP PAINT MATCHING THE PROPER COLOR SHALL BE USED.
- THE MESH SHALL BE INSTALLED ACCORDING TO OWNERS INSTRUCTIONS WITH THE FOLLOWING OPTIONS:
1. PICKETS UP OR DOWN
2. FOLDS FACING INSIDE OR OUTSIDE
- FOR LARGER FENCE DETAILS, VISIT OUR WEB SITE'S TECHNICAL PAGE



NOTE:
THE DEPTH OF THE CONCRETE FOUNDATIONS MUST BE ESTABLISHED ACCORDING TO REGULATIONS IN THE REGION WHERE THE INSTALLATION IS CARRIED OUT. A MINIMUM DEPTH OF 1070 MM (42 IN.) IS RECOMMENDED. THE RECOMMENDED FOUNDATION DIAMETER IS 200 (8 IN.) FOR A COMMERCIAL SITE AND 152 MM (6 IN.) FOR RESIDENTIAL INSTALLATION. REGULATIONS OF THE REGION TAKES PRECEDENCE OVER THE SPECIFICATIONS MENTIONED ABOVE.

IMPORTANT DETAILS ON
INSTALLING THE
ANGLE BRACKET KIT• RECOMMENDATIONS


IT IS VERY IMPORTANT WHEN
INSTALLING TO PAY SPECIAL
ATTENTION TO THE ORIENTATION OF
THE HINGES.

FOR SECURITY REASONS AND
FOR EQUIPMENT PROTECTION, AT
LEAST TWO BRACKETS MUST BE
POSITIONED ON OPPOSITE DIRECTIONS.

THE FOLLOWING FIGURE ILLUSTRATES
THE DETAILS OF THE INSTALLATION.


BRACKET POSITIONED
DOWNWARDS

BRACKET POSITIONED
UPWARDS




OMEGA ECO BRACKET KITS

DOUBLE ANGLE BRACKET KIT 2", 3" □ 4" WITH OMEGA ECO FOR END POSTS



NOTES:
FOR COLORS OTHER THAN BLACK, ALL PARTS ARE
POLYESTER POWDER COATED EXCEPT NUTS □ BOLTS.

DOUBLE ANGLE BRACKET KIT 2", 3" □ 4" WITH OMEGA ECO FOR MID POSTS




SQUARE POSTS INSTALLATION WITH ANGLE BRACKET KIT 14 GA

1 - GRADING

THE GROUND SHALL BE GRADED TO AN EASY EVEN SLOPE ALL ALONG THE LENGTH OF THE AREA WHERE THE FENCE IS TO BE INSTALLED.

2 - INSTALLATION

- INSTALL THE FENCE ALONG THE SPECIFIED AREA. THE FENCE SHALL BE INSTALLED A DISTANCE OF A MINIMUM OF 1" (25 MM) AND MAXIMUM OF 2" (50 MM) ABOVE THE GROUND SURFACE.
- INSERT ALL THE POSTS VERTICALLY AT THEIR PROPER HEIGHT IN CONCRETE. ONCE THE CONCRETE IS SET, THE MESH SECTIONS ARE FASTENED TO THE POSTS WITH THE UNIVERSAL BRACKET KITS 2", 3" OR 4". THE BRACKET'S SLOT ALLOWS FOR ADJUSTMENTS OF $\pm 1\frac{1}{2}$ " (38MM).
- WHEN ANY POST OR WIRE MESH SECTION IS FIELD CUT OR TRIMMED FOR FIT, A ZINC RICH PRIMER MUST BE APPLIED TO THE EXPOSED ENDS. AFTER, AN OMEGA TOUCH-UP PAINT MATCHING THE PROPER COLOR SHALL BE USED.
- THE MESH SHALL BE INSTALLED ACCORDING TO OWNERS INSTRUCTIONS WITH THE FOLLOWING OPTIONS:
1. PICKETS UP OR DOWN
2. FOLDS FACING INSIDE OR OUTSIDE
- FOR LARGER FENCE DETAILS, VISIT OUR WEB SITE'S TECHNICAL PAGE



NOTE:

THE DEPTH OF THE CONCRETE FOUNDATIONS MUST BE ESTABLISHED ACCORDING TO REGULATIONS IN THE REGION WHERE THE INSTALLATION IS CARRIED OUT. A MINIMUM DEPTH OF 1070 MM (42 IN.) IS RECOMMENDED. THE RECOMMENDED FOUNDATION DIAMETER IS 200 [] (8 IN.) FOR A COMMERCIAL SITE AND 152 MM (6 IN.) FOR RESIDENTIAL INSTALLATION. REGULATIONS OF THE REGION TAKES PRECEDENCE OVER THE SPECIFICATIONS MENTIONED ABOVE.

IMPORTANT DETAILS ON INSTALLING THE ANGLE BRACKET KIT

- RECOMMENDATIONS

IT IS VERY IMPORTANT WHEN
INSTALLING TO PAY SPECIAL
ATTENTION TO THE ORIENTATION OF
THE HINGES.

FOR SECURITY REASONS AND
FOR EQUIPMENT PROTECTION, AT
LEAST TWO BRACKETS MUST BE
POSITIONED ON OPPOSITE DIRECTIONS.

THE FOLLOWING FIGURE ILLUSTRATES
THE DETAILS OF THE INSTALLATION.

BRACKET POSITIONED
DOWNWARDS

BRACKET POSITIONED
UPWARDS

